

Appendix 7A: Proposed modification to Standard Special Condition A3.

Definitions and Interpretation

“NTS exit capacity”

shall have the meaning given to the terms “NTS Exit Capacity” and “NTS Offtake Capacity” in the network code;

“NTS exit flat capacity”

shall have the meaning given to the term “NTS Offtake (Flat) Capacity” in the network code;

“NTS exit flow flexibility”

shall have the meaning given to the term “NTS Offtake (Flexibility) Capacity” in the network code;